


Art.-No. 254003

## Grandma's food cover, set of 3

## Protects food from flies



The assembly and disassembly of the screen tent is simple. The mechanism works very similar to an umbrella. When folded, the fly cover can be stowed away to save space or taken with you, for example to a picnic.

Enjoy your food hygienically and cleanly without having to kill insects or use of poison.

Ideal for problems with houseflies, blowflies or fruit flies. Think of outdoor buffets or barbecues, cakes, pies, meat or fruit. There are countless uses for grandma's food cover.

And it is a very simple solution:

Open - place - done!



